


1/19





2/19






3/19





5/19



6/19






FIG. 10 FIG. 9 1012 -912 **EXTERNAL** COMPUTER BOOTED STORAGE DEVICE OR RESTARTED **DRIVERS INSTALLED** -1014 914 LAUNCHER APP IS ONE-BUTTON STARTED AUTOMATICALLY INSTALLATION LAUNCHED (PREFERABLY IN BACKGROUND) 916 LAUNCHER PROGRAM 1016 LAUNCHER ESTABLISHES INSTALLED, IF NOT ALREADY PRESENT **CONNECTIONS WITH** EXTERNAL STORAGE DEVICE THROUGH ASSOCIATED -918 BACKUP SOFTWARE **DEVICE DRIVER** INSTALLED, IF NOT ALREADY PRESENT -1018 **POLL OR WAIT** 922 FOR BUTTON PRESS COMMUNICATION CHANNEL TYPE IS DETECTED OR **INPUT** -924 USER PROMPTED TO **CONFIGURE BACKUP** (E.G., SOURCE FILES/TYPES)


FIG. 11







9/19


FIG. 13







11/19



12/19




FIG. 18





FIG. 19



14/19

FIG. 20





FIG. 21






FIG. 23





FIG. 24



PCT/US2003/027853

18/19

FIG. 25





FIG. 26



## 19/19

FIG. 27

WO 2004/023262




FIG. 28

